



Part Number	Alternate Part	CD	Qty	UOM	Description
311		NE	3	EA	LIGHT, STORM
313		NE	19	EA	LAMP
7387		NE	10	EA	LAMP
9696	704A46-310-005	AR	1	EA	MOTOR,ELECTRICAL
9696	704A46310005	AR	1	EA	MOTOR,ELECTRICAL
9696	704A46-310-005	AR	1	EA	MOTOR,ELECTRICAL
16935		NE	2	EA	STATIC WICK
20100		NE	1	EA	RELIEF VALVE
22052		NE	5	EA	FLAHLIGHT CHARGE SLEEVE
31071		NE	9	EA	POSITION LIGHT, RED
33949		NE	8	EA	O-RING
40373		NE	1	EA	PACKING - FACET FITTING
42960	704A47-612-052	NE	1	EA	INDICATOR,TACHOMETER
42960	704A47-612-052	AR	1	EA	INDICATOR,TACHOMETER
45072		NE	5	EA	YELLOW FLASH LIGHT BASE
109290		NE	1	EA	GYRO
109290		OH	1	EA	GYRO
130100		AR	2	EA	MOTOR PUMP CATRIDGE
220160		NE	2	EA	SEAL
230850		NE	4	EA	Seal
230870		NE	11	EA	SEAL
322003		NE	2	EA	TERMINAL
414400		NE	113	EA	CELL,BATTERY CVH150KH
414425		NE	11	EA	SENSOR,TEMPERATURE
433000		NE	1	EA	LOX WING NUT
450460		NE	2	EA	Gasket
450490		NE	2	EA	SPACER
450500		NE	2	EA	SPACER
538157		NE	2	EA	OIL SEAL
806518		NE	1	EA	TRANSMITTER
1742439		NE	4	EA	PACKING
3360023		NE	39	EA	HOLLOW WASHER
5800001	117-65066-01	NE	2	EA	Cushion
6890550		SV	1	EA	250-C20C Compressor
7001104		NE	2	EA	BOOT
7002060		NE	1	EA	BEARING
23065121	2524769-14	OH	1	EA	C20 Governor
23069745		SV	1	EA	C20B Turbine Assy
23070606		SV	1	EA	C20 Fuel Control Unit
111720140		NE	4	EA	SEAL
177557400		SV	1	EA	Filter Box, electronic
292501940		NE	2	EA	Seal
301057990		AR	6	EA	PYROMETRIC HARNESS
420800001		AR	2	EA	BLOWER ASSY
634313010		NE	2	EA	PACKING
2307031201		NE	1	EA	GASKET
4263067047		NE	1	EA	BALL PIN
4618048004		NE	24	EA	BRUSH
4619306027		NE	1	EA	SEAL
4619310068		NE	12	EA	PACKING



4638305009		NE	3	EA	Shield
5732068011		NE	5	EA	CLIP
8819925000		AR	1	EA	TEST BOX
9520010794		NE	1	EA	SEAL
9550166270		NE	31	EA	FILTER ELEMENT
9550170770		NE	2	EA	THERMOCOUPLE, DOUBLE
9560170480		NE	10	EA	SEAL, VARILIP
9681501803		NE	1	EA	Packing,Preformed
9681508502		NE	1	EA	PACKING, PREFORMED
9682001003		NE	2	EA	O'Ring
9682001952		NE	2	EA	FCU change O-ring
9682201141		NE	3	EA	O'Ring
9682508403		NE	1	EA	PACKING, PREFORMED
9744017100		NE	5	EA	CIRCLIP
9752008044		NE	5	EA	SEAL, Engine Oil Filter
9752008044		NS	19	EA	SEAL, Engine Oil Filter
9752012044		NE	2	EA	SEAL
9752018044		NE	2	EA	SEAL
9752022044		NE	10	EA	SEAL
9752100120		NE	2	EA	SEAL
9794080203		NE	2	EA	O'Ring
9794410075		NE	4	EA	PACKING, PREFORMED
9794410112		NE	7	EA	PACKING, PREFORMED
9794420150	9682701513	NE	4	EA	PACKING, PREFORMED
9836005010		NE	7	EA	SCREW
9836005018		NE	12	EA	SCREW
9998050021		NE	4	EA	TAB WASHER
00003004-1		NE	3	EA	REFLECTOR,DEVORE LIGHT
00003006-3		NE	2	EA	GASKET
00003020-1		NE	4	EA	DEVORE LIGHT SPRING
00003024-1		NE	2	EA	DEVORE SUPPORT ASSY
00003026-1		NE	2	EA	REFLECTOR SUPPORT,DEVORE
00003027-15		NE	11	EA	CLEAR DEVORE LIGHT LENS
00003028-1		NE	5	EA	DEVORE CONTACT LEAD
00003030-1		NE	1	EA	DEVORE BASE ASSY
037-00028-0005		NE	4	EA	BULB, HIS
037-0007-001		NE	1	EA	LAMPS FOR KI 204
06015-1070		NE	2	EA	HOSE
066-03137-3200		AR	3	EA	SCREEN ED551A
066-03137-3300		AR	1	EA	ELECTRONIC DISPLAY ED551A
066-04021-1111		OH	1	EA	SYMBOL GENERATOR
066-1071-00		OH	1	EA	Transponder, ATC. KXP-756
066-1071-00		AR	1	EA	Transponder, ATC. KXP-756
069-1024-42		AR	1	EA	VHF COMM. TRANSCEIVER
071-00074-0200		AR	1	EA	SWITCHING BOX
071-01439-3100		AR	2	EA	CONTROL PANEL
071-1378-00		AR	1	EA	SENSOR RADAR
10-1949-9-2		NE	4	EA	BELLOWS
10133G41		NE	2	EA	HEADPAD
105-09125.02		NE	1	EA	BUSHING
105-10151.08		NE	4	EA	WASHER



105-13101.25	NE	4	EA	LOCK WASHER
105-131035.05	NE	3	EA	SAFETY LEVER BOLT
105-13201.07	NE	2	EA	BUSHING
105-13221.02	NE	4	EA	FLANGE BUSHING
105-13221.08	NE	1	EA	SPACER
105-13241.02	NE	5	EA	BUSHING
105-14101.90	NE	7	EA	PLAC - OIL LEVEL MARKING
105-20051.81	NE	1	EA	FAIRING LH
105-20151.04	NE	2	EA	SPRING
105-23301.19	NE	2	EA	BUSHING
105-23301.20	NE	2	EA	BUSHING
105-23334.03	NE	1	EA	CONTROL LEVER RH
105-23397	NE	2	EA	HINGE
105-31722.02	NE	2	EA	SLEEVE
105-317261	OH	1	EA	Laminated Pile Assy / Strap Pack
105-31729.02	NE	2	EA	BUSHING
105-31729.03	NE	2	EA	Bushing
105-31729.04	NE	2	EA	Bushing
105-317371.03	NE	1	EA	SLEEVE
105-40213	NE	1	EA	BELLOWS
105-41111.04	NE	2	EA	WASHER
105-42110.16	NE	5	EA	SHIM RING
105-42122.06	NE	4	EA	FLANGE BUSHING
105-42123.10	NE	8	EA	BEARING
105-42124.06	NE	4	EA	FLANGE BUSHING
105-42125-04	NE	1	EA	Bushing
105-45021.66	NE	3	EA	CLAMP
105-45613.02	NE	5	EA	BUSHING
105-46611.11	NE	2	EA	Bolt
105-46611.13	NE	6	EA	BELLOWS
105-46611.23	NE	2	EA	DU-Washer
105-46711.03	NE	7	EA	BUSHING,BEARING
105-50101.02	NE	5	EA	BOLT
105-50101.03	NE	4	EA	WASHER
105-50101.04	NE	5	EA	NUT
105-50101.21	NE	4	EA	BUSHING
105-50101.22	NE	4	EA	NUT
105-60133	NE	1	EA	RING ASSY
105-60351.11	NE	2	EA	WASHER
105-60583.12	NE	1	EA	SPRING
105-60584.09	NE	1	EA	DUTCHMAN DISC.
105-60591.04	NE	2	EA	PIN
105-60591.05	NE	2	EA	SLEEVE
105-60711.05	NE	1	EA	WASHER
105-61711.01	NE	1	EA	WASHER
105-61711.02	NE	1	EA	WASHER
105-61711.03	NE	1	EA	WASHER
105-61711.05	NE	1	EA	WASHER
105-61711.06	NE	1	EA	WASHER
105-62305.01.2	NE	2	EA	SEAL
105-62305.05	NE	2	EA	SEAL



105-62712.02	NE	1	EA	BUSHING
105-79501-37	NE	5	EA	PLAC - NO HANDLING
105-79501.02	NE	4	EA	PLAC - THROTTLE POSITION
105-79501.28	NE	3	EA	PLAC - LH-SLIDING DOOR WH
105-79501.30	NE	4	EA	PLAC - RH-SLIDING DOOR WH
105-79501.38	NE	10	EA	PLAC - NO HANDLING WH
105-79501.42	NE	3	EA	PLAC - DISCON ELEC CONN
105-79501.54	NE	1	EA	PLAC - MIL-L-23699 WH
105-79501.55	NE	4	EA	PLAC - MAX LOAD 44 LBS BK
105-79501.56	NE	4	EA	PLAC - MAX LOAD 44 LBS WH
105-79501.57	NE	1	EA	PLAC - JETTISON
105-79501.63	NE	5	EA	PLAC - APU
105-79501.69	NE	1	EA	PLAC - LH DOOR SLIDE
105-79501.70	NE	1	EA	PLAC - RH DOOR SLIDE
105-79501.71	NE	5	EA	PLAC - FUEL WARN - BLK
105-79501.72	NE	2	EA	PLAC - FUEL WARN - WH
105-79501.73	NE	4	EA	PLAC - DOOR LK OP/CL WH
105-79501.74	NE	2	EA	PLAC - DOOR LK OP/CL WH
105-79501.77	NE	4	EA	PLAC - OPEN SM BK
105-79501.78	NE	7	EA	PLAC - CLOSED WH
105-79501.82	NE	3	EA	PLAC - CABIN AIR
105-79501.83	NE	1	EA	PLAC - ROTOR BRAKE
105-79501.85	NE	1	EA	PLAC - DOOR JETTISON BO
105-79511.44	NE	6	EA	PLAC - OPERATING LIMIT
105-79511.46	NE	5	EA	PLAC - DUR GND OPS SM CYC
105-79511.68	NE	2	EA	PLAC - OAT CAL/AIRSPEED
105-79511.80	NE	2	EA	PLAC - OAT
105-81022.03	NE	2	EA	DISTANCE RING
105-81022.08	NE	2	EA	PIN
105-84917.07	NE	1	EA	PLAC - UNLOCK BEFORE CLOS
105-84917.09	NE	1	EA	PLAC - UNLOCK BEFORE CLOS
105-90802.63	NE	1	EA	EYE BROW LIGHT
105-91902.08 A	NE	2	EA	PLAC - CONT TRIM WH/BLK
105-91902.09	NE	1	EA	PLAC - RPM WARN
105-91902.10	NE	2	EA	PLAC - MIC WH/BLK
105-93910	NE	3	EA	DIFF PRESS SWITCH
105-94575	OH	1	EA	MAST MOMENT XMITTER
10F461	NE	2	EA	POT-01F6267
10F605	NE	2	EA	SWITCH
11-10815P	NE	1	EA	SPHERICAL BEARING
1120-43001.07	NE	1	EA	Bushing
1120-43021.07	NE	2	EA	CLAMP
1121-31501.10	NE	12	EA	BOLT
1121-31501.13	NE	2	EA	HEX HEAD SCREW
1121-31541.13	NE	13	EA	BOLT
1121-51102	NE	1	EA	CLAMP RING
117-150041.15	NE	1	EA	TRIM TAB
117-16013-01	NE	1	EA	STUB SHAFT
117-181001.02	NE	1	EA	WASHER
117-20051-63	NE	1	EA	CLIP
117-21193-09	NE	1	EA	HINGE ASSY, LH



117-212211.10		NE	1	EA	RIB
117-22317-01		NE	2	EA	HAND GRIP ASSY
117-232371		NE	1	EA	HINGE, GOOSENECK
117-23313-04		NE	1	EA	SUPPORT LH
117-23360-01		NE	1	EA	Bracket
117-24177-01		NE	3	EA	PIN
117-24261-03		NE	2	EA	SEAL
117-24261-07		NE	2	EA	SEAL
117-24261-09		NE	2	EA	SEAL
117-24261-11		NE	2	EA	SEAL
117-24264-01		NE	17	EA	SPACER
117-24273-01		NE	1	EA	GUIDE ASSY, LH
117-24274-01	117-24274-101	NE	7	EA	Guide Assy
117-24281-12		NE	1	EA	CATCHER
117-24282-101		NE	1	EA	CATCHER LH
117-24612-01		NE	1	EA	UPP HINGE ASSY LH
117-24618-01		NE	1	EA	Bushing
117-24627-01		NE	1	EA	SHIM
117-24640-03		NE	1	EA	SEAL
117-24640-09		NE	2	EA	SEAL
117-24640-11		NE	1	EA	SEAL
117-30051.13		NE	20	EA	WASHER
117-30106.15		NE	1	EA	FASTENER LH
117-30550.17		NE	1	EA	CAP LH
117-30550.18		NE	1	EA	CAP RH
117-30585		NE	1	EA	RIB 1 ASSY LH
117-30586.01		NE	1	EA	RIB 1 ASSY RH
117-31752.30		NE	2	EA	PLAC - ID PLATE
117-41111-01		NE	1	EA	BOOT ASSY
117-41177-03		NE	1	EA	BELCRANK
117-41308-03		NE	2	EA	BUSHING
117-41309-03		NE	1	EA	BUSHING
117-41309-05		NE	3	EA	BUSHING
117-41312.03		NE	1	EA	BRAKE LINER
117-41630.05		NE	2	EA	BUSHING
117-42140-01		NE	1	EA	BELCRANK ASSY
117-44001.05		NE	1	EA	BUSHING
117-44120		NE	2	EA	LINK
117-460381	D107613	NE	1	EA	Cyclic Trim Actuator
117-50002.17		NE	2	EA	SHIM
117-509001 "A1"		NE	1	EA	BONDING JUMPER
117-509051 "A"		NE	1	EA	BONDING JUMPER
117-61114-01		NE	1	EA	FITTING
117-61138-01		NE	1	EA	Fitting
117-61227-35		NE	1	EA	HOSE
117-61228-11		NE	1	EA	TUBE ASSY
117-61244-01		NE	1	EA	BRACKET ASSY
117-61258-01		NE	3	EA	SEAL
117-61266-01		NE	1	EA	TUBE ASSY
117-61312.03		NE	1	EA	SWITCH, ENG OIL PRESS
117-61313-01		NE	1	EA	XMITTER,ENG OIL PRESS



117-62617-01	NE	2	EA	Bolt
117-62618-01	NE	4	EA	Bolt
117-62619-03	NE	1	EA	Bushing
117-62701-01	NE	1	EA	Truss Support
117-62721-01	NE	1	EA	SIDEWARD LINK LH ALT -03
117-62721-03	NE	3	EA	Sidewards Link, LH
117-62854-03	NE	1	EA	BOLT
117-63223-01	NE	1	EA	SPRING
117-63362-01	NE	1	EA	SLIDE ASSY
117-63432-01	NE	1	EA	ARM
117-63495-01	NE	2	EA	SEAL
117-63521-01	NE	1	EA	ARM ASSY
117-64146.01	NE	1	EA	SEAL
117-64152-01	NE	1	EA	Fuel Qty Transmitter
117-64152.03	NE	2	EA	FUEL LEVER TRANS
117-64155-01	NE	2	EA	Seal
117-64155.03	NE	2	EA	METAL O SEAL
117-64156.03	NE	4	EA	METAL O SEAL
117-64157-01	NE	4	EA	Seal
117-64157-03	NE	2	EA	Seal
117-64158-01	NE	2	EA	Seal
117-64159-01	NE	1	EA	Seal
117-64168-05	NE	7	EA	FUEL CAP
117-64569.03	NE	2	EA	SWITCH, FUEL PRESS
117-64620-13	NE	1	EA	PROTECTOR
117-65065.01	NE	12	EA	SHIM
117-651121	OH	1	EA	EXHAUST STACK
117-662711	NE	2	EA	SHAFT SEAL ASSY
117-710351	NE	4	EA	CLAMP
117-72171.01	NE	1	EA	FAN
117-72186-05	NE	1	EA	VENT CONTROL ASSY
117-740121-19	NE	3	EA	PLAC - UNLK DR BEFORE CL
117-740121.07	NE	6	EA	PLAC - FIRE BOTTLE
117-740121.12	NE	3	EA	PLAC - R/H DOOR JETTISON
117-740121.71	NE	2	EA	PLAC - FUEL TANK BK
117-740121.72	NE	3	EA	PLAC - FUEL TANK WH
117-740121.92A	NE	2	EA	PLAC - MAX GROSS 3350 BK
117-740121.93A	NE	1	EA	PLAC - MAX GROSS 3350 WH
117-740131-106	NE	6	EA	PLAC - MAX GROSS 2850 BK
117-740131-106A	NE	4	EA	PLAC - MAX GROSS 3350 BK
117-740131-107	NE	2	EA	PLAC - MAX GROSS 2850 WH
117-740131.08	NE	5	EA	PLAC - FIRE BOT TP/PS WH
117-740131.11	NE	6	EA	PLAC - LH-DOOR JETTISON
117-740131.110A	NE	1	EA	PLAC - OAT CAL >3000
117-740131.12	NE	4	EA	PLAC - RH-DOOR JETTISON
117-740131.13	NE	4	EA	PLAC - DOOR JETTISON EXT
117-740131.15	NE	7	EA	PLAC - DOOR JETTISON INT
117-740131.20	NE	5	EA	PLAC - UNLK DR BEF CL WH
117-740131.22	NE	3	EA	PLAC - MAX MASS BK
117-740131.23	NE	6	EA	PLAC - MAX MASS
117-740131.25	NE	3	EA	PLAC - NO STEP BK



117-740131.27	NE	1	EA	PLAC - LH-SL DR OPEN BK
117-740131.28	NE	3	EA	PLAC - RH-SL DR OPEN BK
117-740131.29	NE	5	EA	PLAC - LH-SL DR OPEN WH
117-740131.30	NE	4	EA	PLAC - RH-SL DR OPEN WH
117-740131.31	NE	4	EA	PLAC - RH JACK HERE BK
117-740131.32	NE	4	EA	PLAC - RH JACK HERE WH
117-740131.33	NE	5	EA	PLAC - LH JACK HERE BK
117-740131.34	NE	5	EA	PLAC - LH JACK HERE WH
117-740131.39	NE	6	EA	PLAC - HANDLE HERE BK
117-740131.40	NE	5	EA	PLAC - HANDLE HERE WH
117-740131.47	NE	10	EA	PLAC - NO PUSH BK
117-740131.48	NE	4	EA	PLAC - NO PUSH WH
117-740131.51	NE	1	EA	PLAC - DIR OF ROT WH
117-740131.59	NE	2	EA	PLAC - INTERCOM BK
117-740131.60	NE	2	EA	PLAC - INTERCOM WH
117-740131.63	NE	2	EA	PLAC - APU BK
117-740131.64	NE	11	EA	PLAC - APU WH
117-740131.76	NE	3	EA	PLAC - OPEN WH
117-740131.77	NE	4	EA	PLAC - OPEN WH
117-740131.78	NE	2	EA	PLAC - CLOSED BK
117-740131.85	NE	3	EA	PLAC - FIRE EXTINGUISHER
117-740131.88	NE	3	EA	PLAC - OAT CAL 2850
117-740131.93	NE	2	EA	PLAC - MAX GROSS 3200 BK
117-740131.94	NE	6	EA	PLAC - MAX GROSS 3200 WH
117-740131.97	NE	4	EA	PLAC - OAT CAL/SPAS OPS
117-740171.02	NE	2	EA	PLAC - DIRECT OF DOOR
117-740171.04	NE	1	EA	PLAC - DIRECT OF DOOR
117-75058-09	NE	1	EA	TUBE ASSY
117-88679	NE	2	EA	LEVER ASSY
117-88680	NE	1	EA	BONDING JUMPER
117-891011.13	NE	5	EA	PLAC - FUEL CAP
117-89131.01	NE	2	EA	FUEL LEVEL TRANS
117-89605-05	NE	2	EA	WASHER
117-89783-01	OH	1	EA	Fuel Pump Fail Indicator
117-902121	NE	1	EA	TQ GAUGE - BK
117-91113-01	NE	2	EA	ROD ASSY
117-92031.03	NE	3	EA	CONTROL UNIT
117-92034-01	NE	1	EA	SWITCH PANEL
117-92039.03	NE	1	EA	POWER SUP. EMERG. LIGHTS
117-92049-01	NE	1	EA	POWER SUPPLY
117-93830	NE	1	EA	SHORTING PLUG
117-94036-05	NE	1	EA	XMSN OIL PRESS
117-94042-03	NE	1	EA	AIRSPEED IND
117-94048-03	NE	1	EA	MASTER LIGHT
117-94051-07	NE	3	EA	TOT INDICATOR
117-94053-03	NE	4	EA	Indicator, Triple Tach.
117-94054.03	NE	1	EA	INDICATOR, FUEL QTY
117-94056.03	NE	3	EA	INDICATOR, N1
117-94058.07	NE	2	EA	INDICATOR, ENG OIL TEMP/P
117-94061-01	NE	1	EA	CONTROL BOX
117-94362.03	NE	1	EA	BRACKET

6505A-3053



117-945641		NE	1	EA	MAST MOMENT INST.
117-94626-01		NE	2	EA	RAM PLATE, LH
117-94626-02		NE	2	EA	RAM PLATE
117-98338.13		NE	1	EA	PLAC - ID LABELS
117-98537		NE	2	EA	WIRING HARNESS
117-E0001-12		NE	1	EA	SUPPORT
117-E0001-16		NE	1	EA	BRACKET
117-E0001-17		NE	1	EA	ECU MOUNT
117-E0001-38		NE	1	EA	BRACKET
117-E0011-8		NE	1	EA	Hose, LH
117-SB20-101-3.1		NE	1	EA	SB KIT
117-SB90-109-3.1		NE	1	EA	SB KIT
12150PCR106		NE	5	EA	NUT
12840G01		NE	2	EA	BOOM
12S1-14-1BB		NE	1	EA	LOCKING PIN
13-4615P		NE	2	EA	BUSHING
130-2403		NE	1	EA	ELT TEST BUTTON
130849-1		NE	47	EA	PLATE,GROUNDING
140-1731		NE	3	EA	SWITCH, PROTECTIVE GUARD
14027-7		AR	1	EA	CARGO HOOK, BREEZE-EASTERN A25LT
1429-30		NE	2	EA	PCB,VOLTAGE REGULATOR
148600-09		NE	2	EA	ACTUATOR
150-0003	A2BE	NE	2	EA	Radar Altimeter Power Supply
158991-1		NE	1	EA	CYLINDER ASSEMBLY,7,95LT
158991-3		NE	5	EA	GAS CYLINDER ASSY 8.28L
15R10-1AC		NE	3	EA	NUT
15S1-1-1AC		NE	6	EA	STUD ASSY
15S1-3-1AC		NE	5	EA	FASTENER
17255-1		NE	1	EA	Base Mount
17343-62-340		NE	1	EA	FIRE DETECTOR (RED)
17343-62-410		NE	1	EA	FIRE DETECTOR
1742227-01		NE	1	EA	INDICATOR
18786-200		NE	1	EA	LEG,MAIN LANDING GEAR
18804G02		NE	1	EA	CORD KIT,MIC SHEILD W/PLU
19090-100-00		AR	1	EA	CYLINDER,BRACE STRUT
19095-100		NE	1	EA	TRUSS ACTUATING JACK
1B6972-2		NE	2	EA	CHIP DETECTOR
1C27-19		NE	3	EA	Fuel Pump Cartridge
1C64-2		OH	1	EA	Fuel Pump Assy
1D1772-1		NE	5	EA	CHIP DETECTOR
1D1772-2		NE	1	EA	DEBRIS MONITOR HOUSING
1HM1		NE	1	EA	SWITCH
1TL1-2		NE	1	EA	SWITCH
2-400F03D10X10M/		NE	1	EA	NOISE FILTER
200735-0		AR	2	EA	L/H Float Cover
200740-1+		AR	2	EA	BOTTLE, REAR
200877-1		AR	2	EA	CYLINDER ASSY, EMERG. FLOAT GEAR
201-136C21		NE	1	EA	FORKED HEAD
20580-000-01		NE	2	EA	BRAKE,WHEEL
20T3		NE	10	EA	BULB
218571-0		AR	2	EA	L/H FLOAT COVER



218572-0		AR	3	EA	AIRCRAFT FLOATATION GEAR
218573-0		AR	3	EA	PROTECTIVE FLAP
2200-10		NE	1	EA	RELAY,REVERSE CURRENT
2200-10		OH	1	EA	RELAY,REVERSE CURRENT
2201959-1		NE	1	EA	DUCT
2202200-3-1		NE	1	EA	ECU COMPLETE
2202392-2		NE	1	EA	LINE
22271BC060036L		NE	8	EA	BOLT
22272BC030010L		NE	10	EA	SCREW
23032-048		OH	2	EA	Starter Generator
23033-1141		NE	6	EA	ST/GEN BRUSHES
2306-562-20-11		AR	1	EA	FUEL QTY INDICATOR
2309-155-00-10		NE	3	EA	VOLTMETER,DC
2309-163-20-10		AR	1	EA	AMMETER, INDICATOR
2309-361-20-10		AR	1	EA	AMMETER, INDICATOR
23350AC100LE		NE	1	EA	WASHER,LOCK
2412-20		NE	1	EA	24V-12V CONVERTER
2541-28-10-0S		NE	14	EA	STAT-O-SEAL
25F1180		NE	1	EA	RED LITE CARTRIDGES
25F1181-A		NE	1	EA	AMBER LITE CARTRIDGES
26475P02		NE	2	EA	DOME FILT
267900-001		NE	4	EA	BOSE HEADSET
26S8-4		NE	9	EA	STUD
26S98-6-1DA		NE	3	EA	STUD
2A100001G		NE	1	EA	MEDICAL STATIC INVERTER
2V702		NE	1	EA	HALOGEN LAMP
30050-0909-1121		AR	1	EA	RECEIVER PROCESSOR UNIT
303R		NE	16	EA	LAMP
3057-204-1		AR	1	EA	INDICATOR, T4 CELCUI
3057-3-136-4		AR	1	EA	Indicator
31-4079-9		NE	1	EA	RED LENS
31-4658-1		NE	4	EA	LIGHT SUB ASSY
313R		NE	76	EA	LAMP
332A44-0012-00		NE	1	EA	SKID,TAIL
332A97-0000-00		NE	1	EA	SYSTEM TEST CASE
34170-1-X		NE	1	EA	DOME LIGHT ASSY
350A08-2493-71		NE	10	EA	KIT
350A14-0020-1201		AR	1	EA	Vertical Fin, Upper
350A14-0021-0901	350A14-0021-0401	AR	1	EA	LOWER STABILIZER ASSY
350A21-0026-0002		AR	2	EA	FAIRING LOWER REAR
350A21-0032-1001		AR	1	EA	DOOR ASSY LH, CARGO COMPARTMENT
350A21-0032-11		AR	1	EA	DOOR ASSY,RH CARGO COMPARTMENT
350A21-1247-0051		NE	1	EA	REAR STRUCTURE FRAME
350A23-0032-0501		AR	1	EA	COWLING ASSY, CENTRE
350A23-0032-0601		AR	1	EA	COWLING ASSY, REAR
350A23-0032-0901		AR	1	EA	COWLING ASSY, FRONT ARRIEL
350A23-0034-02		AR	1	EA	COWLING ASSY,TGB
350A23-0040-00		AR	1	EA	FAIRING LOWER FRONT
350A25-0000-0109		AR	1	EA	CANOPY ASSY
350A25-0110-0001		AR	1	EA	DOOR, REDUCED LH, HIGH VISIBILITY
350A25-0110-0101		AR	1	EA	DOOR, REDUCED RH, HIGH VISIBILITY



350A25-0120-0002		AR	1	EA	DOOR SLIDING LH
350A25-0120-0102		AR	1	EA	DOOR SLIDING RH
350A25-1324-20		NE	2	EA	ROLLER
350A25-1346-20		NE	2	EA	Pad, Friction
350A27-3170-04		AR	1	EA	COLLECTIVE PITCH LEVER,PILOT
350A27-3171-0401		AR	1	EA	LEVER COPILOT, WITH TWIST GRIP
350A31-1854-21		NE	6	EA	BOLT
350A32-0110-00	350A32-0100-10M	NE	1	EA	Epicyclic Gear Assembly
350A32-0110-00	350A32-0100-10M	OH	1	EA	Epicyclic Gear Assembly
350A32-0120-00		OH	1	EA	Epicyclic Reduction Gear Assy
350A32-0300-04	350A32-0310-00	NE	1	EA	Main Gearbox Assembly
350A32-0310-02	350A32-0310-00	OH	1	EA	Bevel Reduction Gearbox Assy (incl Oil Pump)
350A32-0400-00		NE	1	EA	Oil Pump Assembly
350A32-0500-02		OH	1	EA	Brake Assembly, Main Rotor
350A32-1075-20		NE	1	EA	Sun Gear
350A32-3143-03		NE	1	EA	MGB Bevel Gear Set
350A33-0200-05	350A33-0200-04	AR	1	EA	BOX, TAIL GEAR
350A33-2153-00		NE	5	EA	BEARING, SPHERICAL LAMINATED
350A34-1023-21		NE	1	EA	FLANGE, SPLINED
350A34-1080-02		AR	1	EA	AIR INTAKE ARRIEL
350A41-1016-72		NE	6	EA	SHOE, PROTECTIVE REAR SHORT
350A55-1005-21		NE	3	EA	SEAL GAUGE
350A58-0101-1304		AR	1	EA	COWLING, MGB, RH
350A58-0101-1404		AR	1	EA	COWLING, MGB, LH
350A58-0104-0201		AR	1	EA	COWLING, MGB, UPPER LH
350A58-0104-0301		AR	1	EA	COWLING, MGB, UPPER RH
350A58-0108-0601		AR	1	EA	FAIRING, JUNCTION ARRIEL
350A58-0109-1801		AR	1	EA	ENGINE COWLING ARRIEL
350A58-1008-01		AR	1	EA	COWLING, OIL COOLER AIR INTAKE
350A75-2050-06		OH	2	EA	ABSORBER, SHOCK, L/G
350A75-2057-20		NE	1	EA	CYLINDER
350A84-0047-00		NE	3	EA	BELT ASSY (RESCUE HOIST)
350A89-0000-09		SV	1	EA	MOTOR, WIRED WIND SHIELD WIPER
350P61-1386-00		AR	1	EA	PCB, 33 ALPHA
350P61-1386-01		AR	1	EA	PCB, 38 ALPHA
350P61-1388-01		AR	1	EA	PCB, 35 ALPHA
350P61-1389-01		AR	1	EA	PRINTED CIRCUIT BOARD, 37ALPHA
355A07-1447-81		NE	1	EA	MODIF.
355A13-0520-0301		AR	1	EA	STABILIZER HORIZONTAL
355A21-0522-0802		AR	1	EA	FAIRING, INTERLAY LOWER, LH
355A21-0522-0902		AR	1	EA	FAIRING, INTERLAY LOWER, RH
355A21-2020-0101		NE	1	EA	FLARED STRUCTURE
355A23-0500-0002		NE	1	EA	TAIL BOOM
355A23-0520-0001		AR	1	EA	COWLING, REAR, TAIL BOOM
355A32-0200-04		NE	1	EA	Gearbox, Combiner
355A32-0600-03M		AR	1	EA	REDUCTION GEAR TAPERED ASSY
355A32-0701-00M		NE	1	EA	PUMP OIL MGB
355A35-2002-05		NE	2	EA	HOUSING, COUPLING
355A35-2034-02		NE	2	EA	SHAFT, ENGINE
355A58-0513-02		NE	1	EA	COWLING INST, ENGINE
355A58-0516-0404		NE	1	EA	FIREWALL, INST, AUTOMATIQUE



355A58-0517-0201		NE	1	EA	FIREWALL ASSY
355A61-5213-0004		NE	1	EA	PCB,10ALPHA
355A75-1370-04		NE	1	EA	Actuator
35890-AD-M		AR	1	EA	ANEMOMETRE 200 KNOTS
360A32-1135-03		NE	7	EA	PLATE,ROTOR BRAKE
365A07-52B6971		NE	1	EA	AMELIO ENLARGED SLIDING DOOR
365A07-52B6972		NE	2	EA	AMELIOR ENLARGED SLIDING DOOR
365A08-0971-0201		NE	1	EA	RAIL,UPPER
365A08-0976-02		NE	1	EA	LH MIDDLE RAIL
365A21-3752-05		NE	2	EA	MODIF
365A23-4210-02		NE	1	EA	T.G.B. ATTACHMENT TUBE
365A24-0110-0701		NE	1	EA	REMOVABLE COWLING MGB,RH
365A24-8003-02		NE	1	EA	FIXED LH MGB COWLING
365A25-3472-00		NE	2	EA	HINGE ARM ASSY
365A25-3480-00		NE	3	EA	STOP
365A27-3761-06		AR	1	EA	MICROSWITCH LINK
365A31-2031-20		NE	6	EA	PIN,BLADE
365A32-2760-02		NE	8	EA	OIL SIGHT
365A32-4208-20		NE	12	EA	GIMBLE JOINT PIN
365A34-1033-01		NE	2	EA	COUPLING
365A34-6102-01		NE	1	EA	FRONT SHAFT, REAR TRANSMISSION
365A38-0130-0101		NE	2	EA	SUPPORT MAIN GEAR BOX
365A52-1368-00		NE	3	EA	HOSE
365A53-1318-03		NE	3	EA	HOSE
365A55-3037-03		NE	6	EA	HOSE
365A58-1102-1701		NE	1	EA	REMOVABLE FIREWALL
365A61-495B-HW02		NE	1	EA	MODIF.
365A64-2064-0401		NE	1	EA	LIGHT SELECTOR UNIT
365A77-225B-HW01		NE	1	EA	FLOATATION.
365A82-1142-0006		NE	1	EA	SLIDING DOOR,LH.ENLARGED
365A82-1170-0202		NE	1	EA	BAD WEATHER RH COLORLESS GLASS
365A82-1170-0302		NE	1	EA	BAD WEATHER LH COLORLESS GLASS
365A84-3090-18		NE	1	EA	FAIRING, FWD LH
365AEX-400B-WK00		NE	2	EA	MODIF
365APQ-400B-HR00		NE	1	EA	MODIF
365ATZ-100B-HR03		NE	1	EA	MODIF
365ATZ-101B-HR01		NE	2	EA	FLOATATION.
365ATZ-102B-HR00		NE	2	EA	MODIF
365ATZ-103B-HR00		NE	2	EA	RIGTH PROTECTOR INSTALLED.
365ATZ-150B-HW00		NE	1	EA	FLOATATION.
365ATZ-400B-WK00		NE	2	EA	MODIF
365ATZ-402B-HX00		NE	2	EA	MODIF.
365P61-4537-02		NE	2	EA	SUPPORT,ASSY
366A32-1062-06		NE	1	EA	M.G.B.BASE ASSY
37230-1		NE	1	EA	Bulb
37480-28		AR	1	EA	INDICATOR,VERTICAL SPEED (FEETS)
39.1-1100-02		NE	1	EA	Spas Actuator
391D		NE	2	EA	FUEL VIEW
393004-051		OH	1	EA	Fuel Gauge
4-301-106-04	ACA684F40Y2	NE	2	EA	Oil Filter Element Assembly
4-301-106-04	WF335201	NE	2	EA	Oil Filter Element Assembly



4-301-216-02	WF338189	NE	2	EA	Fuel Filter Element
4-301-216-02	038072-18	NE	2	EA	Fuel Filter Element
4-301-283-08		OH	1	EA	Fuel Control Unit
400-012785-00		AR	1	EA	Wulfsberg RT-406F
4021541-671		OH	1	EA	GYRO HORIZON
402A0004		NE	8	EA	RING
40308-1		NE	1	EA	43-AH BATTERY
4051-8-021-2396		NE	3	EA	SEATBELTS
418-00468-800		AR	1	EA	UNIT,AMPLIFIER,TRIM ACTUATOR (KNOTS)
418-00478-204		AR	1	EA	ACTUATOR
418-00478-304		AR	1	EA	PITCH ACTUATOR
418-00478-554		AR	1	EA	ACTUATOR AUTOPILOT
418-00487-010		NE	1	EA	UNIT,TRIM CONTROL VC85
418-00529-102	704A47-1320-42	AR	2	EA	TRIM ACTUATOR
418-00561-612		AR	1	EA	CYLINDER,ROLL CYCLIC
418-00562-312		AR	1	EA	CYLINDER,PITCH CYCLIC
418-00618-400		AR	1	EA	UNIT,AP CONTROL
418-00666-100		AR	1	EA	BOX,TRIM
419-00320-580		AR	1	EA	CDV 85 COUPLER
41S001		NE	2	EA	STACO SWITCH
433G20-2		NE	1	EA	FUEL FILTER
454C01		NE	1	EA	DRAIN VALVE
461-00306-411		AR	1	EA	INDICATOR
462-00310-101		AR	1	EA	UNIT,COMPENSATING
471A0021-01		NE	1	EA	SCREW
471A0022-01		NE	5	EA	WASHER
471A0024-01		NE	2	EA	WASHER
471A0025-01		NE	2	EA	BUSH
48S08A		NE	1	EA	SWITCH
495SE832-08-4		NE	2	EA	KNOB
500-0759		NE	1	EA	DAMPING TUBE
500-12Y		NE	2	EA	3 FREQUENCY PLB WITH SPEECH
500DCF		AR	2	EA	HORIZON, GYRO
503102-415		NE	1	EA	SEAT BELT
5035P242		NE	1	EA	ALTIMETER
504339-201-1028		OH	1	EA	SHOLDER HARNESS
504339-211-1028		NE	1	EA	SEAT BELT
52351CBD050N		NE	2278	EA	NUT,ANCHOR
524-061 Reserved		AR	1	EA	GENERATOR,STARTER
52VVA		NE	1	EA	MAST MOMENT HARNESS
5330-14-214-3624	R13316	NE	18	EA	Gasket alum
5330-14-214-3624	DHS613-595-09	NE	18	EA	Gasket alum
5633-707-80-12	704A47-612-113	OH	1	EA	DELTA NG INDICATOR
5633-713-20-10		AR	2	EA	INDICATOR NG
5638-710-20-12		AR	1	EA	INDICATOR NR/NTL
57-03-11		AR	1	EA	INVERTER
57859-225		NE	2	EA	BOLT
579-108-00		NE	3	EA	STOP, SPHERICAL, LAMINATED
58-04-1-13		AR	1	EA	INVERTER
586165-3		NE	1	EA	COOLING TURBINE
5876-703-00-10		NE	1	EA	INDICATOR,ROTOR RPM



5876-703-00-10	AR	1	EA	INDICATOR, ROTOR RPM
5985-99-902-0944	AR	1	EA	LOGIC UNIT
60-3474-5	NE	4	EA	POWER SUPPLY
61355-300-1	AR	1	EA	INDICATOR, RADIO ALTIMETER
64140-955-1	AR	1	EA	ALTIMETER FEET
64251-903-2	AR	1	EA	TRANSMITTER, TORQUEMETER
645-208-1	AR	1	EA	TACHOMETER
64550-005-1	NE	4	EA	TRANSMITTER TACHY
648-20-02	AR	1	EA	BOILER ALIMENTATION
64818-014-1	AR	1	EA	Oil Pressure, Indicator
64818-015-1	AR	1	EA	TEMPERATURE INDICATOR
64818-019-1	AR	1	EA	OIL PRESSURE INDICATOR
64818-300-1	AR	1	EA	FUEL PRESSURE, INDICATOR
651-1041-932	AR	1	EA	INDICATOR, HSI
6832AS25	NE	22	EA	BULB
6838-1001	NE	34	EA	LAMPS
6838AS15	NE	65	EA	LIGHT BULB, 3V
6839AS25	NE	8	EA	BULB
686-4035-500	NE	1	EA	PCB, AUXILIARY ALARMS
7000H SPORT LE	AR	14	EA	PELTOR HEADSET
704A-47-723-028	AR	1	EA	CAUTION WARNING PANEL
704A33-633-21151	NE	1	EA	STOP ASSY, SPHERICAL
704A33-698-002	NE	12	EA	Bush Rubber
704A46570055	NE	1	EA	BOX, MASTER, ELECTRICAL
704A46570104	NE	1	EA	MASTER, ELECTRICAL, RIGHT
704A46570105	AR	1	EA	MASTER, ELECTRICAL, LH
704A47-6411-11	NE	1	EA	TRANSMITTER
704A47-651-094	NE	1	EA	Fuel Quantity Transmitter
706A32-713-000	NE	3	EA	WIPER BLADE, RH
7131-3	NE	3	EA	BUSHING
716-586-1	AR	1	EA	FUEL QTY INDICATOR
7360-1	NE	1	EA	CABLE LINE
741RS01	NE	1	EA	SERVO REPLACEMENT KIT
742A00009-01	NE	2	EA	O-RING
7460-1	NE	1	EA	LEVER ASSY
76-7055	NE	1	EA	SWITCH
763-273	NE	23	EA	THERMOSTAT
76370-010	AR	1	EA	HOIST, ELECTRICAL
788664-3	NE	1	EA	NR/NTL INDICATOR
805-10800-001	AR	1	EA	TRANSMITTER/RECEIVER COMPUTER
8107-101-00-12	NE	2	EA	TRANSMITTER, ENGINE OIL PRESSURE
811B	NE	2	EA	DAVTRON CLOCK
82018-05601	NE	4	EA	CAP HOUSING ASSY
82110-09301	NE	4	EA	SPRING
8500C	SV	1	EA	Chadwick
87232009-2	NE	2	EA	PROBE, TEMPERATURE
884984-5	NE	2	EA	PRESS VALVE (ECU)
894TS05NY	NE	4	EA	SWITCH, LANDING GEAR
908-111250-24	NE	5	EA	SCREW
910GC01SC1	NE	1	EA	KIT
93A100-30	AR	1	EA	VOICE-RECORDER A100A



9411-620		NE	8	EA	BRUSH
990-0035-1		NE	3	EA	SCREW
9EL095528-00		NE	2	EA	AFT POSITION LIGHT LENS
A100-83		AR	1	EA	CVR COMPLETE INSTALLATION
A1054		NE	2	EA	VOLUME CONTROL
A218-101145-00		NE	1	EA	SWITCH
A3108		NE	1	EA	CLAMP(SEARCH LITE)
A350CNRDBKLG28		NE	1	EA	INSTRUMENT POST LIGHT
A5026780	704A34-310-006	NE	1	EA	PUMP,HYDRAULIC (6L/MN)
A6582		NE	2	EA	GRIMES S/L GEAR
A6870736		NE	2	EA	RING
A6870737		NE	2	EA	RING
A6944-1		NE	8	EA	SEARCHLITE PARTS
A6954		NE	8	EA	SEARCHLITE PARTS
A7635A7		NE	1	EA	CLAMP-117 ANTI-COL
AA489-2		NE	2	EA	FILTER LITE
AA95-758		NE	1	EA	CONTROL HEAD
AC-8101-1007RT1		NE	1	EA	REPAIR TUBE
AC67244	704A44-831-112	NE	1	EA	Servo Control Without Lock, RH/LH
AC67246		NE	1	EA	Servo
ACRO 216		NE	1	EA	C20/B/R Turbine Install Kit
AE706272-1		NE	1	EA	HOSE ASSY
AFG0332159		NE	1	EA	STRAP,SAFETY
AFG0367606		NE	2	EA	AUTO STRAP BLOCK
AFG0367746		NE	1	EA	SEAT BELT
AGNF15E1.3544.		NE	1	EA	DBL ROW BALL BRG.
AJ3-45		NE	3	EA	LOCK
AML 91		NE	2	EA	LOX SWITCH BULBS
AML30		NE	6	EA	LOX SWITCH
AML51-F10W		NE	7	EA	LOX SWITCH COVER
AN101013		NE	2	EA	BOLT
AN3115-1		NE	2	EA	PLUG
AN500D4-4		NE	2	EA	SCREW
AN815-6D		NE	2	EA	AN FITTING
APT100-1000-20		NE	5	EA	PRESSURE TRANSDUCER
AS350B2		OH	1	EA	AIRFRAME
AS3582-132		NE	16	EA	O-RING
AT420000		NE	1	EA	DIGITAL CHRONOMETER
AT575-129W-TNCF		NE	1	EA	ANTENNA
AT575-9		NE	1	EA	ANTENNA
AUX.OVHD.PANEL		NE	3	EA	AUX OVHD PANEL (UNLIT)
AW-5-T-30		NE	4	EA	DZUS FASTENER
AW-5-T-40		NE	1	EA	DZUS FASTENER
B05-05-005-11		NE	37	EA	SCREW
B05-05-005-12		NE	31	EA	SCREW
B3550-11-305		NE	1	EA	DOME LIGHT ASSY, NO LENS
B4717		NE	1	EA	CHIP DETECTOR HOUSING
BA28-24-BW3		NE	1	EA	LIGHT ASSY., INSTRUMENT
BA502		NE	1	EA	TIGHTENING CLAMP
BA503		NE	1	EA	INST ADAPTER CLAMP
BACS21X11		NE	5	EA	STUD



BALLOON MOUNT		NE	2	EA	BALLOON PUMP MOUNT
BHC1110		NE	1	EA	ELECTRO-VALVE
C20525000		NE	2	EA	WHEEL
C2400		NE	1	EA	MAG COMPASS
C256A710105200		NE	1	EA	Emergency Floatation Gear Fixed Parts
C533A111210171		NE	1	EA	Emergency Floatation Gear Provision Kit
C622A2006601		NE	6	EA	PIN BLADE,UNEQUIPPED
C632A1102601		NE	1	EA	RING FIXED NITRIDED
CB00279-2D119		NE	2	EA	SAND FILTER HINGE
CC-3251		NE	3	EA	SNAP VENT
CD00279-2D100		NE	1	EA	SAND FILTER ACTUATOR
CE45B		NE	3	EA	LOCK-MOM SW/BLK SLIDE
CN6ME-R		NE	2	EA	ROD END
CP1976B1		AR	1	EA	SWITCH SELECTOR TB31
CTJ122E10A		NE	1	EA	MODULE
CTJ720E01B		NE	1	EA	MODULE
D105100-0-11		NE	4	EA	GASKET
D107318-21		NE	1	EA	BOOST PUMP REPAIR KIT
D120-P2-T		AR	1	EA	DIGITIZER
D50060-11		NE	4	EA	CLIP
D50060-7		NE	17	EA	SPACER
D50068-1N		NE	1	EA	MAP CASE
D50069-1W		NE	1	EA	MAP CASE
DA-27		NE	21	EA	DEVORE BULB
DHS613-595-07		NE	30	EA	SEAL
DHS775-160-40		NE	7	EA	BODY, LIGHT
DIN1481-1,5X8		NE	2	EA	PIN
DIN1481-2,5X14		NE	3	EA	ROLL PIN
DIN433-6,4ST50		NE	23	EA	WASHER
DIN472-22X1		NE	2	EA	RETAINING RING
DIN7603A14X20A	DIN7603A14X20AL	NE	43	EA	SEALING RING
DIN963M4X20-4.		NE	100	EA	COUNTERSUNK SCREW
DSR59176-1015		NE	12	EA	SPRING DISC
E11200		NE	2	EA	PISTON
E1T3023-01		NE	1	EA	FREQUENCY ADAPTER
E4165F01		NE	2	EA	FREQUENCY ADAPTOR
EL210-143CKIT01		NE	1	EA	RELAY
EVP310		NE	1	EA	ELECTROVALVE
FDT16163		NE	2	EA	CONTROL ROD
FR2212		NE	1	EA	DETECTOR,SMOKE
FT10865-147		NE	1	EA	GASKET
FU1540-150		NE	2	EA	STRIP SHAPED FUSE
FU1540-300		NE	2	EA	STRIP SHAPED FUSE
G-6250-4		OH	2	EA	SEARCH LIGHT
G45X52X4		NE	1	EA	GASKET
G55-56-7-4		NE	1	EA	Torque Transducer
GA-56		NE	1	EA	GPS ANTENNA, GARMIN
GE-1385		NE	1	EA	BULB
GE-1495		NE	12	EA	LAMP
GE-1683		NE	17	EA	LAMP
GE-303		NE	7	EA	BULB



GE-307	NE	14	EA	LAMP
GE-313R	NE	6	EA	BULB
GE-328	NE	10	EA	LAMP
GE-330	NE	3	EA	BULB
GE-356	NE	5	EA	BULB
GPN300F4	NE	30	EA	PLUG
GTX-327	NE	1	EA	TRANSPONDER /W RACK
H341 AYM	AR	1	EA	HORIZON, GYRO
H4002	NE	1	EA	SEAT BELTS
HBL5278C	NE	3	EA	HUBBELL 110 V SOCKET
HV1205	NE	7	EA	GROMMET
J313PB6	NE	1	EA	SWITCH
JB2504-4SUS	NE	1	EA	SNAP RING
JB2808-2.5AW20	NE	12	EA	PIN
JET27-32V	NE	11	EA	SEAL
JS151	NE	4	EA	ACTUATOR
K016-1	NE	2	EA	GAS SPRING
K056	NE	7	EA	BULB
K402AL	NE	2	EA	CHIP DETECTOR
KS8040B10A12A	NE	1	EA	BEAD CHAIN ASSY
KYNAR-1	NE	5	EA	HEAT SHRINK
L2-105-51	NE	1	EA	ROD END
L22462-100BCL	NE	3	EA	JAM NUT L/H
L531M1043102	NE	2	EA	EC-145 Nose Panel
LN1434-05X25	NE	2	EA	Pin
LN29522-08104	NE	2	EA	BOLT
LN29522-12108	NE	1	EA	BOLT
LN29522S08026	NE	6	EA	HEX BOLT
LN29631A11WS	NE	9	EA	PLAC - GROUND POINT
LN29882-1A2-45	NE	2	EA	RELAYS
LN29930-08X26	NE	1	EA	BOLT
LN29996-04M	NE	3	EA	ANCHOR NUT
LN65045-10	NE	15	EA	WASHER
LN9025-1010L	NE	16	EA	WASHER
LN9037-06045	NE	10	EA	BOLT
LN9082-10X42S	NE	2	EA	BOLT
LN9172AF915	NE	2	EA	HINGE
LN9264-1,5X125	NE	1	EA	LEAD BONDING
LN9264-10X125	NE	1	EA	BONDER ELECTRICAL
LN9355-6X38	NE	5	EA	BOLT
LN9367GE12N2	NE	3	EA	SPHERICAL BRG
LN9367GE6N2	NE	1	EA	SPHERICAL BEARING
LN9367GE8N2	NE	1	EA	SPHERICAL BRG
LN9380M12X1,5X	NE	6	EA	HEX. BOLT
LN9380M6X65	NE	4	EA	BOLT
LOX BOTTLE	NE	3	EA	10 LITTER LOX BOTTLE
M25988/1-928	NE	2	EA	Packing
M3436ND	NE	1	EA	AIR COND CONDENSER MOTOR
M6106/19-012	NE	1	EA	RELAY ALT # JC-D4A-003
M83116E8-2S-3	NE	2	EA	CANNON PLUGS
M83248-1-912	NE	18	EA	PACKING



M83248/1-028	NE	10	EA	PACKING
M83248/1-046	NE	23	EA	PACKING
M83248/1-126	NE	6	EA	ORING
M83723/96K1831	NE	6	EA	CANNON PLUG
M85049/31-14N	NE	1	EA	BACKSHELL
M85049/41-10A	NE	2	EA	CANNON PLUG PARTS
MC235MH089	NE	1	EA	FOULING IND
MDA1427-A-010	NE	1	EA	LAP BELT ASSY
MDE2525-B-010	NE	2	EA	LAP BELT ASSY
MS17990-412	NE	1	EA	QUICK RELEASE PIN
MS17990C403	NE	2	EA	QUICK RELEASE PIN
MS20392-1C13	NE	5	EA	CLEVIS PIN
MS20392-1C15	NE	3	EA	CLEVIS PIN
MS21026E231	NE	1	EA	SWITCH (ICS/TRANSMIT)
MS21027G351	NE	2	EA	SWITCH
MS21042-5	NE	75	EA	LOCK NUTS
MS22034-2	NE	3	EA	CONNECTOR
MS24523-21	NE	1	EA	SWITCH
MS24524-31	NE	1	EA	SWITCH
MS24585-46	NE	3	EA	SPRING
MS24658-23D	NE	1	EA	SWITCH
MS25089-4AR	NE	6	EA	SWITCH
MS25182-2	NE	1	EA	CONNECTOR
MS26574-3	NE	1	EA	CIRCUIT BREAKER
MS27039-C08-07	NE	21	EA	SCREW
MS27649-5	NE	5	EA	BEARING
MS27708-4	NE	2	EA	SWITCH
MS27719-31-1	NE	2	EA	SWITCH
MS28774-028	NE	10	EA	BACKUP RING
MS28774-112	NE	5	EA	RETAINER
MS28775-004	NE	10	EA	O-RING
MS29512-03	NE	14	EA	O Ring
MS29512-04	NE	6	EA	O Ring
MS29512-08	NE	1	EA	O Ring
MS29512-28	NE	74	EA	PACKING
MS29513-011	NE	9	EA	O-RING
MS29513-137	NE	18	EA	PACKING
MS29513-138	NE	9	EA	PACKING
MS29513-338	NE	4	EA	FUEL CAP ORING
MS29561-114	NE	1	EA	PACKING
MS29561-12	NE	19	EA	PACKING
MS29561-122	NE	10	EA	PACKING
MS3101A18-1S	NE	2	EA	CANNON PLUG PARTS
MS3102E14S-7P	NE	1	EA	CANNON PLUG
MS3106A18-1P	NE	1	EA	CANNON PLUG
MS3106A8S-1S	NE	4	EA	CONNECTOR
MS3116F10-98S	NE	1	EA	CANNON PLUG
MS3120E12-10S	NE	2	EA	CANNON PLUG
MS3120E12-3S	NE	2	EA	CANNON PLUG
MS3120F12-10P	NE	3	EA	CANNON PLUG
MS3120F22-55S	NE	1	EA	CANNON PLUG



MS3126F12-3P	NE	2	EA	CANNON PLUG
MS3126F20-41P	NE	1	EA	CONNECTOR
MS3418-18N	NE	6	EA	CANNON PLUG PARTS
MS9020-05	NE	3	EA	O-RING
MS90311-211	NE	2	EA	SWITCH
MS9068-113	NE	8	EA	O-RING
MS9068-123	NE	5	EA	O-RING
MS9068-133	NE	9	EA	PACKING
MS9372-019	NE	7	EA	SEAL
MS9387-010	NE	5	EA	PACKING
MS9387-5	NE	8	EA	PACKING
MS9387-6	NE	9	EA	PACKING
MS9387-8	NE	11	EA	PACKING
MS9388-010	NE	12	EA	PACKING
MS9388-012	NE	8	EA	PACKING
MS9388-017	NE	9	EA	O-RING
MS9388-023	NE	11	EA	PACKING
MS9388-118	NE	17	EA	PACKING
MS9388-140	NE	10	EA	PACKING
MS9388-153	NE	4	EA	PACKING
MS9886-13	NE	8	EA	BOLT
MSP641311B	NE	1	EA	CLAMP
MTA-106D	NE	1	EA	SWITCH
MTL-206P	NE	2	EA	SWITCH
N6019407226	NE	3	EA	REPAIR KIT
N6068757286	NE	2	EA	PRESSURE PLATE ASSY P/N 073-08300
N6079127246	NE	3	EA	FUEL CAP
NAS1149DN816K	NE	200	EA	WASHER
NAS1593-014	NE	20	EA	PACKING
NAS1593-015	NE	5	EA	PACKING
NAS1593-153	NE	4	EA	PACKING
NAS1593-158	NE	8	EA	O-RING
NAS391-B4P	NE	7	EA	DEVORE LENS SCREW WASHER
NAS617-12	NE	8	EA	ORING
NAS617-3	NE	57	EA	PACKING
NAS617-5	NE	9	EA	PACKING
NT-450	NE	1	EA	RADIO
NT150	NE	2	EA	VHF FM TRANSCEIVER
NY6MO-1-2RP	NE	1	EA	CONNECTOR
OR105X2-70FKM5	NE	5	EA	O-RING
OR12-42X1-78-7	NE	9	EA	O-RING
OR35X1.5-83FKM	NE	17	EA	O-RING
OR41,2-3-72NBR	NE	7	EA	PACKING
OR9.2X2.62VITO	NE	10	EA	PACKING
P401	NE	1	EA	FUEL VENT VALVE
P94C16-602	AR	3	EA	PUMP,FUEL BOOSTER
PC-251	NE	2	EA	INVERTER,FLIGHT
PC3-1/2	NE	10	EA	STUD
PF3-1/2-38	NE	9	EA	STUD
PH502-BKC	NE	1	EA	PITOT TUBE
PR2	NE	5	EA	BULBS



PR3		NE	6	EA	BULBS
PS3-1/2		NE	9	EA	SPRING
R13316-Z12		NE	1	EA	SEAL
R5108		NE	2	EA	DBL TAPERED RING
R5308		NE	2	EA	NUT
R5608		NE	1	EA	UNION
RB50AV 24V		SV	1	EA	Red Box DC Power Pack 24 Volt 50 Amp
RCA15BK-1		AR	1	EA	DIRECTIONAL GYRO
RT-138F		NE	1	EA	FM TRANSCIEVER
RT-450		NE	1	EA	FM TRANSCIEVER
S1509AP-SE		AR	1	EA	HOOK,RELEASE
S67-2002		NE	2	EA	RADAR ALT ANT
S8990-124		NE	2	EA	PACKING
SB BK117-20-109		NE	1	EA	PARTIAL SB KIT
SC4161B		AR	1	EA	SERVOCONTROL,TAIL ROTOR
SC5081		AR	1	EA	Servo
SC5082		AR	1	EA	Servo
SC5083		NE	3	EA	SERVO-CONTROL,RH/LH,WITH LOCK
SC5083		OH	2	EA	SERVO-CONTROL,RH/LH,WITH LOCK
SC5084		OH	2	EA	SERVO CONTROL,FRONT,WITH LOCK
SC8031-1		OH	1	EA	SERVO-CONTROL,MAIN ROTOR
SC8034-2		OH	1	EA	SERVO CONTROL, MAIN ROTOR
SC8042	704A44-831-102	OH	1	EA	SERVO-CONTROL,FRONT AND LH
SC8043 Reserved		AR	2	EA	SERVO-CONTROL,RH
SKFAY-5		NE	1	EA	BEARING(FUEL CONTROL QUAD
SL2286-140		NE	10	EA	Fastener
SL2286-80		NE	10	EA	SCREW
SL607M4-9S		NE	2	EA	INSERT
SL61WM14P		NE	1	EA	WASHER
SL644-08-4		NE	8	EA	INSERTS
SL850-M5C10C		NE	4	EA	INSERT
SL850-M6F5C		NE	3	EA	INSERT
SLR2286-2		NE	30	EA	LOCK RING
SP9025		NE	7	EA	MICRO-SWITCH
SRI41,3-2,45-1		NE	4	EA	BACK-UP RING
T6408-103		NE	5	EA	SLIDER BLOCK
T6411-01		NE	5	EA	PLUG
T6658-03		NE	1	EA	SPRING GUIDE
T6670-101		NE	4	EA	LATCH ASSY
T6676-101		NE	1	EA	ROLLER LATCH ASSY
T6683-101		NE	1	EA	PUSH PULL ROD ASSY
T6686-101		NE	1	EA	PUSH PULL ROD
T6694-146		NE	1	EA	TRIKER UPPER RH
TH250 / TH350		NE	2	EA	CONTROL HEAD
TLF 817		NE	2	EA	SUMP DRAIN
TLF321H1		NE	1	EA	CONNECTOR TUBE
TLF455L55		NE	1	EA	ROD ASSY
V15R14-1-1AA		NE	9	EA	MUTTER NUT
V951L61-4BP		NE	1	EA	LIFT-SPRING
V951L80-1X1BP		NE	2	EA	LATCH
W1284C		NE	5	EA	CLEAR LENSE



XD69-277-075	NE	3	EA	FASTENER
XD69-277-080	NE	3	EA	FASTENER
YAJ119.607.200	NE	6	EA	PC Link
Yokes	SV	1	EA	Yokes